

## **Curing Tank Heater**

The curing tank heater is used to control water temperature in concrete curing tanks. The unit includes 2 thermostats; one adjustable between 35° and 95°F; the second maintains the element at a safe operating temperature.

- 110 VAC
- 1000 watts
- Adjustable thermostat
- · Incolloy-shielded heating element
- Stainless steel construction
- · Thermostatically controlled
- 3 pronged grounded plug



TH-100

## PLEASE READ THE FOLLOWING REQUIREMENTS BEFORE USING THE TH-100

- -Put the unit in water no less than 12" to 16" deep at all times. Plug the unit into a 15 amp/gfi circuit.
- -Clean the unit properly (build up from the tank water can greatly affect the efficiency of the unit). Use the "CLR" or other lime/calcium cleaner for build-up. This MUST be done while the unit is off, unplugged, and removed from the tank.
- -If the unit fails, unplug it, remove it from the tank, and check the fuse (the unit may need to be cleaned and maintained).
- -This unit carries a 90 day warranty from the date of purchase; in order for the warranty to be in effect, a proof of purchase date is required.
- -Any misuse or negligence voids the warranty.
- \*\*Before returning to the distributor, a return goods authorization must be issued.
- \*\*Proper packaging is required.
- \*\*The manufacturer has the right to void the warranty if the above requirements are not met.